

#5 Short Sink Flange Assembly (#12506-C)

Allows an additional 2 1/4" clearance between the bottom of the disposer and the floor.

Installation

1. Unscrew the three backup screws (8) until they are flush with the upper mounting ring (7) surface. Pry the retaining ring (9) free from the strainer flange (3) with a screwdriver and separate all mounting assembly parts (3, 4, 6 - 9).
2. Form a 3/4 inch thick ring of top grade oil base putty around the sink opening (use non-hardening putty). Insert the sink flange (3) into the sink opening and press firmly in place. Clean away any excess putty.
3. From underneath the sink, place the strainer fiber gasket (4), adapter mounting flange (5), backup ring (6), and upper mounting ring (7) over the sink flange (3) and hold them up to the sink. Fit the retaining ring (9) into the groove on the sink flange to hold the mounting parts in place.
4. Tighten the three backup screws (8) evenly until the backup ring (6) draw snugly against the underside of the adapter mounting flange (5).
5. Position the disposer for plumbing hookup and check the location of the keyhole slots in the disposer body flange.
6. Attach two screws through opposite holes in adapter mounting gasket (10) and into the threaded fasteners of the mounting flange (5). The screws should be protruding approximately 1/4 inch below the adapter mounting gasket.
7. Position the disposer beneath the adapter mounting gasket (10) and engage the two protruding screws in the key hole slots in the disposer body flange. Assemble the remaining screws (11). Tighten all screws evenly.

PARTS

1 Stopper (#1876)	7 Mounting Flange (#5141)
2 Splash Baffle (#70966)	8 Backup Screw (#5147)
3 Strainer Flange (#5170-AC)	9 Retaining Ring (#5166)
4 Str. Flange Gasket (#1160)	10 A. Mounting Gasket (#11016)
5 A. Mounting Flange (#11189-T)	11 Screw (#1491)
6 Backup Flange (#5150-E)	

